


Welcome to your GSP 670 mini-guide



EPOS | SENNHEISER

Mini-guide

Switching the headset on/off

To turn the headset off, turn the volume wheel all the way down (counterclockwise). To turn it on, turn the volume wheel slightly up (clockwise). A slight resistance can be felt, signaling that the headset has now been turned on or off.

Pairing mode

Switch the headset on, hold the slider button down on the headset for 2 seconds until the LED flashes blue and red.

Pairing with the GSA 70 dongle

Put the headset in pairing mode, then put the GSA 70 in pairing mode by pressing the button until the LED also flashes blue and red. When paired, the headset will prompt "dongle connected" and LED on both headset and dongle will be purple.

Clear the pairing list for Bluetooth devices

To clear the pairing list, simply go to your device and select the GSP 670 from the list of saved devices.

Click on 'Forget this device', and afterwards your GSP 670 will not connect to this device anymore.

Connecting to a smartphone

Put the headset in pairing mode, enable Bluetooth® on your smartphone, then select the GSP 670.

Connecting to multiple devices

The GSP 670 can be paired with multiple devices at the same time. To connect to both the GSA 70 dongle and a mobile device, first put the GSP 670 into pairing mode. Then put the GSA 70 dongle into pairing mode. Once the GSP 670 and GSA 70 are paired, put the GSP 670 into pairing mode again. Enable Bluetooth on the mobile device and select the GSP 670 when it pops up on the screen. When the GSP 670 connects with the mobile device, it will automatically pair again with the dongle and both the mobile device and GSA 70 dongle will be connected with the GSP 670.

Installing the Gaming Suite

To install the Gaming Suite Software, go to eposaudio.com/gaming/downloads

Muting the microphone

Lift the microphone up to mute.

Charging the Headset

To charge the headset, plug the USB charging cable into the head-set and the other end into a USB port. 20+ hours of play time on Bluetooth® and 16 hours on low-latency wireless. Play for 2 hours on a 7 minute fast-charge. The GSP 670 can be used while charging!



Adjusting the volume

The GSP 670 has two separate volume controls. The bigger volume wheel adjusts the game audio, while the smaller volume wheel controls the chat audio, making it easier to manage the volume levels on the fly.



Request battery status

Press slider button down quickly for 1 second. Voice guidance will verify the battery status. Battery status also shown in Gaming Suite.



Other questions

Contact our product service support at eposaudio.com/support